

Návod k použití, údržbě a bezpečnostním opatřením

Tento manuál slouží jako průvodce pro správné používání, údržbu a bezpečné zacházení se zbožím. Prosím, pečlivě si přečtete všechny pokyny před uvedením výrobku do provozu.

Bezpečnostní pokyny

- Používejte zboží pouze k určenému účelu. Nebezpečí výbuchu. Nesprávné užití, plnění, skladování může zapříčinit zranění, smrt nebo hmotnou škodu.
- Nikdy neplňte láhev tekutinou, směsí plynů (hlavně hořlavými plyny) nebo pevnými částmi. Věnujte zvláštní pozornost plnění láhve – dbejte, aby se do nádoby přes plnicí pin nedostaly žádné nečistoty (používejte krytku plnicího pinu).
- Nikdy žádným způsobem neupravujte tuto láhev. V žádném případě na povrchu lahve nedělejte vrypy nebo díry. Nepoužívejte vzduchovou láhev, která je viditelně poškozená na povrchu nebo ve vrstvách pod povrchem. V takovém případě musí láhev znovu projít inspekci ve firmě, která se zabývá testováním tlakových lahví. Láhev by měla projít inspekci i v případě vystavení vysokých teplot, ohni nebo pokud se účastní nehody.
- Láhev musí být chráněna proti vlivu kyselin, pohonných látek, tekutin obsahujících glykol a oleje.
- Vyvarujte se přetlakování.
- Uchovávejte mimo dosah dětí, pokud není určeno pro dětské použití.
- Ventil/regulátor smí být instalován nebo vyměněn pouze k tomu vyškolenou osobou.
- Vyvarujte se vystavení holé kůže unikajícímu vzduchu při našroubování a vyšroubování láhve do zbraně. Unikající plyn by mohl způsobit popálení kůže.

Plnění vzduchové láhve

Vzduchová láhev může být plněna našroubovaná na zbraň nebo samostatně. Plní se pomocí Fill Nipple na straně regulátoru. Plňte pouze stlačeným vzduchem. Vzduch do láhve vpouštějte pomalu. Teplota povrchu láhve při plnění nesmí překročit 50 °C.

Tlak, na který se může plnit vzduchová láhev je max. 3000 psi nebo 4500 psi dle typu láhve, kterou máte. Nikdy neplňte na vyšší tlak!!!

Údržba a čištění

Nepoužívejte agresivní chemikálie ani abrazivní materiály. Pravidelně kontrolujte stav zboží a příslušenství.

Záruka a servis

Zboží je dodáváno se standardní zárukou. V případě závady kontaktujte autorizovaný servis nebo prodejce. Neprovádějte neodborné opravy, mohlo by dojít ke ztrátě záruky.

Likvidace výrobku

Po skončení životnosti výrobku jej likvidujte ekologicky, podle místních předpisů. Nepatří do běžného komunálního odpadu.

V případě dalších dotazů nás neváhejte kontaktovat. Děkujeme, že jste si vybrali naše zboží!

Objednávky, technická podpora, dotazy, servis, velkoobchod, množstevní nákupy

Marcel Nebuchla - tel. 603 843 000, e-mail: info@rprshop.cz

AIR CYLINDERS

Instructions for Use, Maintenance, and Safety Precautions

This manual serves as a guide for the proper use, maintenance, and safe handling of the product. Please read all instructions carefully before putting the product into operation.

Safety Instructions

- Use the product only for its intended purpose. Explosion hazard. Improper use, filling, or storage may cause injury, death, or property damage.
- Never fill the cylinder with liquid, gas mixtures (especially flammable gases), or solid particles. Pay special attention during filling — ensure no contaminants enter the cylinder through the fill nipple (use the fill nipple cap).
- Never modify the cylinder in any way. Do not scratch or puncture the surface of the cylinder under any circumstances. Do not use an air cylinder that is visibly damaged on the surface or in the layers beneath. In such cases, the cylinder must be re-inspected by a company specializing in pressure vessel testing. Inspection is also required if the cylinder has been exposed to high temperatures, fire, or involved in an accident.
- The cylinder must be protected from acids, fuels, glycol-containing fluids, and oils.
- Avoid overpressurization.
- Keep out of reach of children unless specifically designed for child use.
- The valve/regulator may only be installed or replaced by a trained professional.
- Avoid exposing bare skin to escaping air when screwing the cylinder into or out of the weapon. Escaping gas may cause skin burns.

Filling the Air Cylinder

The air cylinder can be filled while attached to the weapon or separately. Filling is done via the Fill Nipple located on the side of the regulator. Fill only with compressed air. Introduce air into the cylinder slowly. The surface temperature of the cylinder during filling must not exceed 50°C.

The maximum pressure for filling the air cylinder is 3000 psi or 4500 psi, depending on the type of cylinder. Never exceed the specified pressure!

Maintenance and Cleaning

Do not use aggressive chemicals or abrasive materials. Regularly check the condition of the product and accessories.

Warranty and Service

The product comes with a standard warranty. In case of a defect, contact an authorized service center or dealer. Do not attempt unauthorized repairs, as this may void the warranty.

Product Disposal

At the end of the product's life, dispose of it in an environmentally friendly manner according to local regulations. Do not dispose of it with regular household waste.

If you have any further questions, do not hesitate to contact us. Thank you for choosing our product!